




DSP-15L(T)


GERMANY DNH WW Ltd DNH GmbH Phone.....+ 44 1908 275 000

Phone... + 49 040 6569 30-0 Fax..... + 49 040 6569 30-30 E-mail.....dnh@dnh.de

DNH Speakers Inc

Phone.....+ 1 484 494 5790 Fax.....+ 1 484 494 5793 E-mail..dnh@dnhspeakers.com





Sec	Secondary			
nomina	I tappings			
1:4	25,0 W			
1:3	14,5 W			
2:4	9,5 W			
1:2	8,0 W			
3:4	4,0 W			
2:3	2,4 W			



Sound pressure levels at 1W/1m SPL vs Freq Solution SPL vs Freq SPL vs Freq	60								<u>am</u> s
55 10 10 10 10 10 10 10 10 10 10 10 10 10	0								1,1,1
55 10 10 10 10 10 10 10 10 10 10 10 10 10	75								
55 10 10 10 10 10 10 10	10								
550000000000000000000000000000000000000	5							\longrightarrow	
500000000000000000000000000000000000000	10							" \	
5	15		\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	\mathcal{J}				\mathbb{H}	
5	10						`\\\\\	Т	
55	15				'	ŭ V\	\mathcal{M}_{Λ} \mathcal{M}	J _	
dBSPL SPL VS Freq	0					ζ,			
	dBSPL			SPL vs	Freq				

-41 K-4

44mm

Standard Bracket

Antistatic PA

Specifications				
Material / Color	ASA / RAL 7035			
Mounting	Bracket			
Termination	Screw terminal			
Weight w/transformer	1,9 kg			
IP-rating	67			
Max. / min. amb. temp	90°C / -50°C			
Rated power	25W			
SPL 1W/1m	110 dB			
SPL rated power	122 dB			
Effective freq. range	290 –11000 Hz			
Dispersion (-6dB) 1kHz / 4kHz	81° / 37°			
Directivity factor, Q	4,5 / 9,6			
Options	Impedances, colors, labels			

Installation, Operation and Maintenance Procedures

Optional Bracket

Stainless steel

- Remove lid by four screws, lead cable through the cable gland and connect to terminal 70V (white green) or 100V (white - red).
- Choose required power on the transformer.
- Check that the gasket is fitted correctly on to the lid. Do not use any lubricants on the gasket.
- Screw lid back into place by four screws with a torque of 1,8 Nm to assure the IP rating.
- To change the position of the loudspeaker, please adjust the standard U- bracket (by loosening / tightening the screws) as required.
- DSP-15L(T) can be supplied with 3 different bracket systems, according to customer requirements.
- For optimum performance, always use the correct voltage / power and operate within the frequency limits as stated.
- Do not open loudspeaker when energized.
- This loudspeaker is supplied with two years warranty against defective workmanship.
- Available with an aluminum swivel bracket.